




YUNAS CEILING FAN INSTALLATION INSTRUCTIONS




WARNING
Before installation make sure that electric supply cables are not live


- 1.- Join the clamp and rod with bolt.
- Hang the down rod with the ceiling hook.




- 2.- Slide up the upper canopy on the rod from bottom end up to some height (Keeping wider side upward) and tighten the canopy screw.
- Slide up lower canopy on down rod (Keeping the wider side downward) up to upper canopy.



- 3.- Screw up the connection box (connected with fan motor) with the down rod, until the split pin hole of connection box and down rod comes in alignment.




- 4.- Pass the split pin through the hole and splits its legs.




- 5.- Insert the electric cables in the hole provided on the upper side of down rod and take out in the connection box and connect the leads with connector provided in the connection box

OR


- If the cables are already provided and connected with connector, insert the cable in down rod upwards from connection box side and take out from the hole on the top of down rod.
- Connect the cable with power supply, according to the diagram.
- For earthing connect the cable with terminal provided.



- 6.- Slide down the lower canopy (connection box cover) and seat on the connection box by aligning the hole of connection the box and lower canopy now tighten the screw in the hole.
- Make sure that canopy is not in contact with motor.
- Loosen the screw of the upper canopy, slide it up to ceiling and tighten the screw again.



- 7.- For fitting the three blades, unscrew the screws with spring washers and rubber seal from the motor and tighten the screw by passing through the holes of blades carrier and rubber seals. For other two blades, repeat the same process.



CONTENTION DIAGRAM

